





SWINGING BALLET

SWINGING BALLET IS A REGISTRATED DESIGN BY COEN MUNSTERS 2009



SWINGING BALLET H6	BASE: 6 X E14 / 220V / MAX. 40W - CHAIN CA. 1,5 MTR.
12910 SWAROVSKI® STRASS®	COLORS 00 01 02 05 10 12 13 14 16 SHADE 301 310 320 377 391
SWINGING BALLET H12	BASE: 12 X E14 / 220V / MAX. 40W - CHAIN CA. 1,5 MTR
12914 SWAROVSKI® STRASS®	COLORS 00 01 02 05 10 12 13 14 16 SHADE 301 310 320 377 391
SWINGING BALLET H18	BASE: 18 X E14 / 220V / MAX. 40W - CHAIN CA. 1,5 MTR
12918 SWAROVSKI® STRASS®	COLORS 00 01 02 05 10 12 13 14 16 SHADE 301 310 320 377 391
SWINGING BALLET F1	BASE: 1 X E27 / 220V / MAX. 100W, INCL. REGULAR / DIMMER
12980	COLORS 00 01 02 05 10 12 13 14 16 SHADE 301 310 320 377 391
SWINGING BALLET T1	BASE: 1 X E27 / 220V / MAX. 60W
12970	COLORS 00 01 02 05 10 12 13 14 16 SHADE 301 310 320 377 391
SWINGING BALLET T1	BASE: 1 X E27 / 220V / MAX. 60W
12972 SWAROVSKI® STRASS®	COLORS 00 01 02 05 10 12 13 14 16 SHADE 301 310 320 377 391
SWINGING BALLET W1	BASE: 1 X E14 / 220V / MAX. 40W
12950 SWAROVSKI® STRASS®	COLORS 00 01 02 05 10 12 13 14 16 SHADE 301 310 320 377 391
SWINGING BALLET W2	BASE: 2 X E14 / 220V / MAX. 40W
12954 SWAROVSKI® STRASS®	COLORS 00 01 02 05 10 12 13 14 16 SHADE 301 310 320 377 391

COLORS	02 CHROME CHROME
	05 BRONZE ALTMESSING
	10 BLACK MATT SCHWARZ MATT
	12 BLACK GLOSSY SCHWARZ POLIERT
	13 WHITE GLOSSY WEISS POLIERT
	14 WHITE MATT WEISS MATT
	16 MATT NICKEL NICKEL MATT

SWINGING BALLET W3	BASE: 3 X E14 / 220V / MAX. 40W
12958 SWAROVSKI® STRASS®	COLORS 00 01 02 05 10 12 13 14 16 SHADE 301 310 320 377 391
SWINGING BALLET H5	BASE: 5 X E14 / 220V / MAX. 40W
12922 SWAROVSKI® STRASS®	COLORS 00 01 02 05 10 12 13 14 16 SHADE 301 310 320 377 391
SWINGING BALLET H7	BASE: 7 X E14 / 220V / MAX. 40W
12926 SWAROVSKI® STRASS®	COLORS 00 01 02 05 10 12 13 14 16 SHADE 301 310 320 377 391
SWINGING BALLET H10	BASE: 10 X E14 / 220V / MAX. 40W
12930 SWAROVSKI® STRASS®	COLORS 00 01 02 05 10 12 13 14 16 SHADE 301 310 320 377 391
SWINGING BALLET H14	BASE: 14 X E14 / 220V / MAX. 40W
12934 SWAROVSKI® STRASS®	COLORS 00 01 02 05 10 12 13 14 16 SHADE 301 310 320 377 391
SWINGING BALLET H17	BASE: 17 X E14 / 220V / MAX. 40W
12938 SWAROVSKI® STRASS®	COLORS 00 01 02 05 10 12 13 14 16 SHADE 301 310 320 377 391
SWINGING BALLET H23	BASE: 23 X E14 / 220V / MAX. 40W
12942 SWAROVSKI® STRASS®	COLORS 00 01 02 05 10 12 13 14 16 SHADE 301 310 320 377 391

SHADE	301 WHITE WEISS
	310 CREME CREME
	320 BLACK SCHWARZ
	377 BROWN BRAUN
	391 RED ROT

GENERAL INFORMATION: - OTHER COLORS ON REQUEST
 - CYRSTAL: SWAROVSKI® STRASS®
 - MIDDLE BASE ARTICLE 12910, 12914, 12918: OTHER LENGHTS ON REQUEST